

Assembly Instructions

- 1.) Find And Extend The Center Line For Cleat And Cleat Cover Upward Approx. 5'-0" (Line "A"). This Will Be Your Point of Reference.
- 2.) Pole Should Be Braced To Prevent Rotation During Installation of Channel. A Second Person Holding The Channel While Installing Screws Is Helpful.
- 3.) Position The Notched End Of The Halyard Cover Down And In The Opening In The Cleat Cover
- 4.) Align The Edge Of The Piano Hinge With Line "A" (Adjust Cover To Be On Center). Use #8 X 3/4" Self Drill/Self Tapping Screws (Pilot Holes May Be Used). Install (6) Screws. Suggestion: Install (1) Upper & Lower Screw (X & Y) To Secure Channel, Prior To Installing Final (4) Screws.
- 5.) Adjust (2) Screws, Already Installed In Cleat Box, To Secure Halyard Cover.
- 6.) Note: Channel And Box Open In Opposing Directions.

